



Dear Customer.

There are some instructions for downloading and installing SolidCAM.

If you have any questions please contact Alignex technical support at 952-224-5334 or [support@alignex.com](mailto:support@alignex.com).

Best Regards,

Alignex Technical Support

Alignex Inc.

7200 Metro Blvd

Edina, MN 55439

952-224-5334

[support@alignex.com](mailto:support@alignex.com)

- 1) Download the latest version of SolidCAM from the SolidCAM web site
- 2) Moving from a major version to another (2009 to 2010)
- 3) Installation and updating

Please

### Method for SolidCAM Dongles

Please email Alignex your dongle ID (should be on the dongle) to [support@alignex.com](mailto:support@alignex.com). Alignex will then request a new license file from SolidCAM. From now on SolidCAM's License file will contain only 2 Files:


1. Readme file
2. License File (.lis)

The update of this license file will be done using a new Exe – **RemoteKeyUpdate.exe** that can be found at <http://download.solidcam.info/General/RemoteKeyUpdate.zip>


After you extract the **RemoteKeyUpdate.exe** file, make sure that the two dll's "clnt.dll" and "nclnt.dll" are in the same directory of the EXE. This exe and the two DLL's will be included in SolidCAM 2009 Util folder.

### Performing the dongle update

- Run the remote key update program (**RemoteKeyUpdate.exe**) and browse for the license file.



- After you load the license file, click the button "**Perform Update**". After a few seconds a message will pop up indicating if the update was successful or not.



- Note that it does not matter where you extract the license file, unlike the older method where the files had to be extracted into the util folder.